

Product Data Sheet

www.designcretehq.com

SuperClear™

DESCRIPTION AND USES

DesignCrete® SuperClear™ is a clear, high-build epoxy protective coating used in the DesignCrete® counter top overlay system. This product features exceptional clarity and excellent working properties, leveling, chemical and water resistance. SuperClear™ can be used as a final finish, but for the ultimate in protection and scratch resistance, DesignCrete® FinalCoat™ is recommended as a wear layer.

SURFACE PREPARATION

Apply to properly applied and decorated, thoroughly dry DesignCrete® CounterTop mix. CounterTop mix and all necessary decorative color coats should be allowed to dry a minimum of four hours before application of SuperClear™.

APPLICATION

Mix and apply according to the detailed instructions found in the SuperClear™ product application bulletin. Mix part A and part B in equal amounts and apply by pouring on the surface and spreading with a brush. Allow SuperClear™ coating to completely cure for a minimum of 16 hours before application of DesignCrete® FinalCoat™.

HEALTH AND SAFETY

Avoid contact with skin and eyes. Allow unused material to harden in the mixing container before disposal. Detailed health and safety information is available on the product Material Safety Data Sheet (MSDS).

The suggestions for use and technical data here given are accurate to the best of our knowledge and are offered in good faith. Because the conditions and use of our products are beyond our control, our liability, if any, is limited to the replacement of defective material only. DesignCrete® DISCLAIMS ALL OTHER WARRANTIES relating to our products and DISCLAIMS ALL WARRANTIES RELATING TO THEIR APPLICATION, expressed or implied, INCLUDING but not limited to warranties of merchantability and fitness for a particular purpose. TECHNICAL DATA IS SUBJECT TO CHANGE WITHOUT NOTICE.

Technical Data

Finish:	Gloss
Vehicle Type:	Epoxy Amine
Volume Solids:	100.0%
Coverage:	40-50 sq. ft. per two-gallon kit @ 60-80 mils dry film thickness
Dry Time:	Touch: 60 Minutes Sand: 8 hours Recoat: 16 hours
Sealer:	No sealer coat required.
Reduction:	Product is ready to apply after mixing. Do not thin.
Catalyzation:	Mix part A and part B at a ratio of 1:1 by volume.
VOC:	Zero
Clean Up:	Use acetone to clean tools immediately after application.

DesignCrete®

by Faux Finish Design Studio LLC

1261 Holton Road

Muskegon, MI 49445

Phone: 231-670-0371

www.designcretehq.com

